


SAGITTARIUS


KPO/277/C– Sequenta Pull Out Kitchen Mixer Chrome Fitting Instructions:

Installation Steps:



A. Remove the faucet, then detach the mounting nut and washer.



B. Thread the hoses and mounting stem through the sink's installation hole. Slide the nut and washer onto the hoses, then tighten the screw onto the mounting stem.




C. Connect the pull-down hose to the adapter pipe.




User Manual


Right rotation Switch to "Waterfall" mode.



Left rotation Switch to "Spray" mode.



Press button Toggle to "Ski Mode" (pulsating stream)



Press button Return to standard stream.



The information contained on this page was correct at the date of issue. Fitting dimensions are provided as a guide only. Some variation may occur due to manufacturing tolerances. We pursue a policy of continuing improvement in design and performance of our products and so reserve the right to change specifications without prior notice

FOR FURTHER ADVICE PLEASE CONTACT :-

SAGITTARIUS LTD UNIT 1 LOWER VICTORIA STREET—CHADDERTON—OLDHAM—OL9 9TU TEL:0161 6202029